

BROAD AREA LASER

GaAs Semiconductor Laser Diode
Single Emitter Structure



PRELIMINARY SPECIFICATION

BA Laser

EYP-BAL-0808-08000-4020-CMT04-0000

General Product Information

| Product | Application |
|-------------------------|---------------------|
| 808 nm Broad Area Laser | Material Processing |
| mounted on C-Mount | Medical |
| | |
| | |



Absolute Maximum Ratings

| | Symbol | Unit | min | typ | max |
|---------------------------------|-----------|------|-----|-----|-----|
| Storage Temperature | T_S | °C | -40 | | 85 |
| Operational Temperature at Case | T_C | °C | 5 | | 40 |
| Forward Current | I_F | A | | | 13 |
| Reverse Voltage | V_R | V | | | 0 |
| Output Power | P_{opt} | W | | | 9 |

Measurement Conditions / Comments

non condensing
non condensing
Stress in excess of the Absolute Maximum Ratings can cause permanent damage to the device. Operation at the Absolute Maximum Rating for extended periods of time can adversely affect the device reliability and may lead to reduced operational life.

Recommended Operational Conditions

| | Symbol | Unit | min | typ | max |
|---------------------------------|-----------|------|-----|-----|-----|
| Operational Temperature at Case | T_C | °C | 15 | | 30 |
| Forward Current | I_F | A | | | 12 |
| Output Power | P_{opt} | W | | | 8 |

Measurement Conditions / Comments

measured at position A (see drawing on p. 3)

Characteristics at $T_{amb} 25\text{ °C}$ at Begin Of Life

| Parameter | Symbol | Unit | min | typ | max |
|---------------------------------------|-----------------|--------|-----|-----|-----|
| Center Wavelength | λ_C | nm | 793 | 808 | 823 |
| Spectral Width (FWHM) | $\Delta\lambda$ | nm | | | 6 |
| Temperature Coefficient of Wavelength | $d\lambda / dT$ | nm / K | | 0.4 | |
| Output Power @ $I_F = 12\text{ A}$ | P_{opt} | W | 8 | | |
| Slope Efficiency | η_d | W / A | 0.7 | 0.9 | |
| Threshold Current | I_{th} | A | | | 2.5 |

Measurement Conditions / Comments

see images on page 4

total output measured with integrating sphere

BROAD AREA LASER

GaAs Semiconductor Laser Diode
Single Emitter Structure



RWE/RWL


BAL


DFB/DBR



TPL/TPA

PRELIMINARY SPECIFICATION

BA Laser

EYP-BAL-0808-08000-4020-CMT04-0000

Characteristics at T_{amb} 25 °C at Begin Of Life

| Parameter | Symbol | Unit | min | typ | max |
|---------------------------------------|------------------|---------------|-----|------------|-----|
| Operational Current @ $P_{opt} = 8$ W | I_{op} | A | | | 12 |
| Stripe Width | W_s | μm | | 200 | |
| Cavity Length | L | μm | | 4000 | |
| Divergence parallel (FWHM) | $\Theta_{ }$ | $^{\circ}$ | | 10 | |
| Divergence perpendicular (FWHM) | Θ_{\perp} | $^{\circ}$ | | 30 | |
| Spectral Mode (longitudinal) | | | | Multi Mode | |
| Polarization | | | | TM | |

Measurement Conditions / Comments

Polarization in perpendicular plane

BROAD AREA LASER

GaAs Semiconductor Laser Diode
Single Emitter Structure



PRELIMINARY SPECIFICATION

BA Laser


EYP-BAL-0808-08000-4020-CMT04-0000

Package Dimensions


| | Symbol | Unit | min | typ | max |
|-------------------|--------|------|------|------|------|
| Emission Plane | l | mm | 7.05 | 7.20 | 7.35 |
| C-Mount Thickness | d | mm | | 4 | |

Package Pinout

| | |
|-------------|---------------|
| Cathode (-) | Mounting Wire |
| Anode (+) | Housing |



Package Drawings



BROAD AREA LASER

GaAs Semiconductor Laser Diode
Single Emitter Structure




PRELIMINARY SPECIFICATION

BA Laser

EYP-BAL-0808-08000-4020-CMT04-0000

Typical Measurement Results

Spectrum at Specified Optical Output Power



Performance figures, data and any illustrative material provided in this specification are typical and must be specifically confirmed in writing by eagleyard Photonics before they become applicable to any particular order or contract. In accordance with the eagleyard Photonics policy of continuous improvement specifications may change without notice.


Unpacking, Installation and Laser Safety

Unpacking the laser diodes should only be done at electrostatic safe workstations (EPA). Though protection against electro static discharge (ESD) is implemented in the laser package, charges may occur at surfaces. Please store this product in its original package at a dry, clean place until final use. During device installation, ESD protection has to be maintained.

The BAL diode type is known to be sensitive against thermal stress. Operating at moderate temperatures on proper heat sinks will contribute to a long lifetime of the diode.

The laser emission from this diode is close to the invisible infrared region of the electromagnetic spectrum. Avoid direct and/or indirect exposure to the free running beam. Collimating the free running beam with optics as common in optical instruments will increase threat to the human eye.

Each laser diode will come with an individual test protocol verifying the parameters given in this document.



Complies with 21 CFR 1040.10 and 1040.40